

SNABBGUIDE ENYROOM - ER

OBS! Motorn i er filmduk levereras med färdigprogrammerad fjärrkontroll och förinställda gränslägen.
Denna snabbguide visar hur gränslägen ändras samt hur extra sändare läggs till i motorn.
För fullständig manual se www.support.enyroom.se eller skanna QR-koden nedan.

MOTORN SKA VARA STRÖMSATT INNAN NÄSTA STEG

	STEG 1	STEG 2	
ÄNDRA ÖVRE GRÄNSLÄGE	HÅLL IN UPP + STOPP * till motorn vickar & piper (tar bort befintligt gränsläge)	KÖR TILL NYTT ÖNSKAT ÖVRE GRÄNSLÄGE - Tryck kort på UPP eller NER för finjustering - Håll in för kontinuerlig gång	HÅLL IN UPP + STOPP tills motorn vickar & piper
ÄNDRA NEDRE GRÄNSLÄGE	HÅLL IN NER + STOPP * tills motorn vickar & piper (tar bort befintligt gränsläge)	KÖR TILL NYTT ÖNSKAT NEDRE GRÄNSLÄGE - Tryck kort på UPP eller NER för finjustering - Håll in för kontinuerlig gång	HÅLL IN NER + STOPP tills motorn vickar & piper
PROGRAMMERA IN EXTRA SÄNDARE *	P2 (FJÄRR) (en redan inprogrammerad)	P2 (FJÄRR) (igen)	P2 (NY SÄNDARE *)

KLART!

* OM motorn inte reagerar efter ca 7s kan fjärrkontrollen vara i låst läge, se beskrivning på nästa sida för att låsa upp.

* Exempel på extra/ny sändare: Fjärrkontroll, Autolink och Dry contact transmitter



ART NR 210944-ER
FJÄRR, 1-KANAL



ART NR 210963-ER
Väggsändare, 1-KANAL



SMART HOME
ENYROOM APP



ART NR 210965-ER
Dry contact transmitter



ART NR 210907-ER
Autolink trigger



ART NR 211040
WiFi Box för APP-kontroll



ENYROOM SUPPORT

PROGRAMMERING	ENYROOM-ER	ENYROOM SMART
Öppna för programmering	Bryt - återanslut ström ELLER håll motorknapp till första vick.	Bryt ström & återanslut ELLER tryck kort på motorknapp
Para ihop	Håll in STOPP till första vickningen (ca 3s)	P2 - P2 - NER
Ändra rotationsriktning	Tryck och håll in UPP + NER tills motorn vickar ELLER håll in motorknapp till motor vickat 3 gånger (ca 10s)	Tryck & håll in motorknapp ELLER bryt ström – återanslut - tryck P2 - P2 - UPP
Gå in i gränsläges-programmering	Behövs inte på -ER	P2 - UPP - P2
Ställ in övre gränsläge	Tryck och håll UPP + STOPP	Tryck & håll in STOPP
Ställ in nedre gränsläge	Tryck och håll NER + STOPP	Tryck & håll in STOPP
Efterjustera övre gränsläget	Tryck och håll UPP + STOPP – kör till nytt önskat läge - Tryck och håll UPP + STOPP	(Motorn kör själv till gränsläget) Därefter tryck & håll in UPP + NER - bekräfta nytt läge med STOPP
Efterjustera nedre gränsläget	Tryck och håll NER + STOPP – kör till nytt önskat läge - Tryck och håll NER + STOPP	
Ställ in favoritläge	Håll in favoritknappen ca 3s ELLER P2 - STOPP - STOPP	P2 - STOPP - STOPP
Ändra favoritläge	Kör till ny önskad position och håll FAVORIT-knapp ca 3s	Radera favoritläget och lägg in nytt.
Radera favoritläge	P2 - STOPP - STOPP	(Motorn kör själv till favoritläget) Därefter tryck P2-STOPP-STOPP
Para ihop fler sändare, fjärrkontroll eller sensor	P2 (gammal) - P2 (gammal) - P2 (ny)	P2 (gammal) - P2 (gammal) - P2 (ny)
Radera enskild sändare, fjärrkontroll eller sensor	P2 (behållas) - P2 (behållas) - P2 (raderas)	Endast tillgängligt i ER-systemet
Radera alla gränslägen	P2 - NER - P2	P2 - NER - P2
Radera alla sändare, fjärrkontroll eller sensor	P2 - STOPP - P2	P2 - STOPP - P2
Gå in i/ur dödmansläge	Tryck och håll UPP + NER 5sek och sedan STOPP	P2 - UPP - NER
Aktivera /deaktivera repeaterfunktion	Tryck och håll P2 - (1 vick + 1 pip) - håll kvar 5sek (2 vick 3 pip: repeater på).	Endast tillgängligt i ER-systemet
Aktivera / deaktivera sol-vindsensorn	P2 - UPP - STOPP - (2 vick 3 pip: Aktiveras)	Endast tillgängligt i ER-systemet
Sensorkontrollfunktion	UPP + STOPP + NER (samtidigt) - (2 vick 3 pip: Deaktiveras) (Motor utan kontrollsignal från sensor 30 min)	Endast tillgängligt i ER-systemet
Ändra Dry Contactfunktion	P2 - P2 - STOPP	Bryt ström & återanslut följt av UPP + NER samtidigt och sedan välj funktion på UPP, STOPP, NER eller P2.
Låsa /låsa upp fjärrkontrollprogrammeringsmöjligheter	Håll STOPP 20s Låsa upp: LED blinkar (1-k fjärr) ELLER visar "U" (15-k fjärr) Låsa: LED fast sken (1-k fjärr) ELLER visar "L" (15-k fjärr)	Endast tillgängligt i ER-systemet
Ändra fjärrkontroll mellan ENYROOM SMART och ENYROOM-ER	Ta ut batteriet - Håll P2 medan batteriet sätts tillbaka. ENYROOM-ER: LED x 2 (1-kanals) resp. visar "2" (15-kanals) ENYROOM-SMART: LED x 1 (1-kanals) resp. visar "1" (15-kanals)	Endast tillgängligt i ER-systemet

ANVÄNDNING	ENYROOM-ER	ENYROOM SMART
Kör upp markisen	UPP	UPP
Kör ner markisen	NER	NER
Kör till favoritläge	FAVORIT-knapp ELLER håll STOPP	Tryck & håll in STOPP
Aktivera solautomatik	Tryck SOL-knapp ELLER P2 - P2 - UPP	UPP + STOPP samtidigt
Deaktivera solautomatik	Tryck STRUKEN-SOL-knapp ELLER P2 - P2 - UPP	NER + STOPP samtidigt
Begränsa synliga kanaler	Tryck och håll + och – tills "15" visas. Välj antal visade kanaler med + och – och tryck sedan STOPP	Tryck < + > kort samtidigt ("C" tänds"). Tryck < + > långt samtidigt ("15" tänds) Välj antal synliga kanaler med < >. Bekräfta med STOPP.

MOTORKNAPPEN	ENYROOM-ER	ENYROOM SMART
Kör motorn	Tryck kort, motorn togglar upp, stopp, ner, stopp...	Endast tillgängligt på ER-motorer
Ihop-parningsläge	Håll och släpp efter första vickningen (ca 2 sek)	Tryck kort på motorknappen
Sätt motorn i radiosköldläge	Håll och släpp efter andra vickningen (ca 6 sek)	Endast tillgängligt på ER-motorer
Gå ur radiosköldläge	Tryck kort ELLER bryt och återanslut strömmen	Endast tillgängligt på ER-motorer
Ändra rotationsriktning	Håll och släpp efter tredje vickningen (ca 10sek)	Håll in motorknapp 3sek (vickar)
Nollställ motorn	Håll och släpp efter fjärde vickningen (ca 14sek)	Håll in motorknapp 20sek (vickar)



Sändare märkta med:

DRAPER-ER

...är en ENYROOM-ER sändare

Sändare märkta med:

DRAPER

...är en ENYROOM SMART-sändare

Kommande märkning:

ENYROOM



QUICK GUIDE ENYROOM - ER

OBS! The screen motor is delivered with programmed remote control and end limits.
 This quick guide shows how to change end limits and how to add additional remote controls or transmitters.
 For complete manual see www.support.enyroom.se or scan the QR-code below.

THE MOTOR MUST BE CONNECTED TO POWER BEFORE NEXT STEP

	STEP 1	STEP 2	STEP 3
CHANGE UPPER END LIMIT	HOLD UP + STOP * till motor jog & beep (delete existing upper limit)	RUN TO NEW DESIRED UPPER END LIMIT - Short press UP or DOWN for fine adjust - Hold for continuous running	HOLD UP + STOP till motor jog & beep
CHANGE LOWER END LIMIT	HOLD DOWN + STOP * till motor jog & beep (delete existing lower limit)	RUN TO NEW DESIRED LOWER END LIMIT - Short press UP or DOWN for fine adjust - Hold for continuous running	HOLD DOWN + STOP till motor jog & beep
ADD ADDITIONAL TRANSMITTER *	P2 (REMOTE) (already programmed)	P2 (REMOTE) (again)	P2 (NEW TRANSMITTER *)

READY!

* IF the motor doesn't react after ca 7s the remote might be in locked mode. Please see description on next page to unlock.

* Example of additional transmitter: Remote control, Autolink and Dry contact transmitter



ART NO 210944-ER
Remote, 1-CH



ART NO 210963-ER
Wall transmitter, 1-KANAL



SMART HOME
ENYROOM APP



ART NO 210965-ER
Dry contact transmitter



ART NO 210907-ER
Autolink trigger



ART NR 211040
WiFi Box for APP-control



ENYROOM SUPPORT

PROGRAMMING	ENYROOM-ER	ENYROOM SMART
Set in programming mode	Reconnect power OR hold motorbutton until 1:st jog.	Reconnect power OR shortly press motor button
Pairing	Hold STOP until jog and beep (ca 3s)	P2 - P2 - DOWN
Change direction of rotation	press and hold UP + DOWN until beep and jog OR press and hold motorbutton until 3:d jog (ca10s)	Press and hold motor button until beep and jog OR reconnect power and then P2 - P2 - UP
Enter limit programming mode	No need on -ER	P2 - UPP - P2
Set upper end limit position	Press and hold UP + STOP	Press and hold STOP
Set lower end limit position	Press and hold DOWN + STOP	Press and hold STOP
Adjust upper end limit position	Press and hold UP + STOP – run to new position - Press and hold UP + STOP	(Let motor stop by itself in end position - upper OR lower) Press and hold UP + DOWN - confirm new position with STOP
Adjust lower end limit position	Press and hold DOWN + STOP – run to new position - Press and hold DOWN + STOP	
Set favorite position	P2 - STOP - STOP OR Hold favorite button	P2 - STOP - STOP
Change favorite position	Run to new desired position and hold favorite button	Delete existing favorite position and set a new position
Delete favorite position	P2 - STOP - STOP	(Let motor run to favorite position) Then P2 - STOP - STOP
Pair additional remote, transmitter or sensor	P2 (old) - P2 (old) - P2 (new)	P2 (old) - P2 (old) - P2 (new)
Delete specific remote, transmitter or sensor	P2 (keep) - P2 (keep) - P2 (to delete)	<i>Only in ER-radio system</i>
Delete end limit positions	P2 - DOWN - P2	P2 - DOWN - P2
Delete all remotes, transmitters and sensors	P2 - STOP - P2	P2 - STOP - P2
Enter/Exit Stop-jog-mode	Press and hold UP + DOWN 5sec and then STOP	P2 - UP - DOWN
Activate/Deactivate range extender function	Press and hold P2 (1 jog, 1 beep) - keep hold 5sec -> 2 jog, 3 beep = range extender on	<i>Only in ER-radio system</i>
Activate / deactivate sun-wind sensor	P2 - UP - STOP -> 2 jog 3 beep = Activated	<i>Only in ER-radio system</i>
Sun-wind sensor fault detection function	UP + STOP + DOWN - 2 jog 3 pip = Deactivates (motor without control signal from sensor 30 min)	<i>Only in ER-radio system</i>
Change Dry Contactfunction	P2 - P2 - STOP	Reconnect power; then UP + DOWN followed by choosing function on UP, STOP, DOWN or P2.
Lock/unlock remote programming ability	Hold STOP 20s Unlock: LED flashes (1-ch remote) OR shows "U" (15-ch) Lock: LED x 1 (1-ch) OR shows "L" (15ch)	<i>Only in ER-radio system</i>
Change remote mode between ENYROOM SMART and ENYROOM-ER	Remove battery - Hold P2 while replacing battery. ENYROOM-ER: LED x 2 (1-ch remote) OR show "2" (15-ch) ENYROOM SMART: LED x 1 (1-ch) OR show "1" (15-ch)	<i>Only in ER-radio system</i>

USAGE	ENYROOM-ER	ENYROOM SMART
Run screen upwards	UP	UP
Run screen downwards	DOWN	DOWN
Run to favorite position	FAVORITE button OR hold STOP	Press and hold STOP
Activate sun automatic	SUN button OR: P2 - P2 - UP (2 jog 3 Beep: Activates)	UP + STOP simultaneously
Deaktivate sun automatic	CROSSED-SUN button OR: P2 - P2 - UP	DOWN + STOP simultaneously
Set number of visible channels	Press and hold + and – until "15" shows. Choose desired ammount visible channels with + and – and then press STOP	Press < and > short ("C" shows). Press and hold < and > ("15" shows). Choose desired ammount visible channels with < >. Confirm with STOP.

MOTOR BUTTON	ENYROOM-ER	ENYROOM SMART
Run the motor	Shortly press, motor togles up, stop, down, stop...	<i>Only in ER-radio system</i>
Pairing state	Hold and release after 1:st jog (ca 2 sec)	Short press
Radio lock mode	Hold and release after 2:nd jog (ca 6 sec)	<i>Only in ER-radio system</i>
Disable Radio lock mode	Press shortly OR reconnect power	<i>Only in ER-radio system</i>
Change direction of rotation	Hold and release after 3:rd jog (ca 10 sec)	Hold and release after 1:st jog (ca 3 sec.)
Factory set motor	Hold and release after 4:th jog (ca 14 sec)	Hold ca 20sec. Jog.



Transmitter with logo:

DRAPER-ER

...is a ENYROOM-ER transmitter

Transmitter with logo:

DRAPER

...is a ENYROOM SMART-transmitter

Future logo:

ENYROOM